



MDT

Version 04.22.26

USER MANUAL

STALKER CORE BUTTSTOCK

**HAVE QUESTIONS OR
NEED ADDITIONAL SUPPORT?**

support@mdttac.com
+1 (604) 393-0800

TOOL REQUIRED

5/16" Ball-End Hex L-Key

INSTALLATION

- Attach the buttstock onto the chassis and insert the 3/16"-24 screw (Provided with the chassis) into the hole of the buttstock.
- Using the 5/16" L-Key, tighten screw to contact plus a 1/4 turn.

WANT TO LEARN MORE?

CHECK OUT OUR OVERVIEW VIDEO

