



Version 08.06.26

USER MANUAL

POLYMER MAGAZINE

**HAVE QUESTIONS OR
NEED ADDITIONAL SUPPORT?**

**support@mdttac.com
+1 (604) 393-0800**

TOOL REQUIRED

Flat Head Screw Driver

FOLLOWER REMOVAL

1. **DO NOT** try to pry off the bottom base plate.
2. Take a flat head screw driver, and push down on the rear of the follower so the front of the follower can pop up and out of the body.
3. Slide the follower forward and out of the feedlips.
4. To re-assemble reverse the previous steps.