



Version 01.15.26

USER MANUAL

**300PRC/338LM
3 ROUND MAGAZINE**

**HAVE QUESTIONS OR
NEED ADDITIONAL SUPPORT?**

**support@mdttac.com
+1 (604) 393-0800**

TOOL REQUIRED
Flat Head Screw Driver

FOLLOWER REMOVAL

1. DO **NOT** try to pry off the bottom base plate.
2. Take a flat head screw driver, and push down on the rear of the follower so the front of the follower can pop up and out of the body.

FOLLOWER INSTALLATION

1. Compress the spring against the follower and slide into the body of the magazine, making sure the front of the follower slides under the front retention tabs.

**NEED TO ADJUST YOUR FEEDLIPS?
CHECK OUT OUR VIDEO**

